



SUPPLEMENTARY  
INSTALLATION INSTRUCTION

SIGMAFORM AUSTRALIA  
Instructions for preparation of Insulation  
Semi Conductive Screen Cut Back Edge for  
Solid Dielectric Cables

REF CODE: 060188