




STEP 1 CUT TO REQUIRED SIZE




STEP 2



STEP 3



STEP 4




NOTES:

1. TERMIMESH CAN BE SUPPLIED FROM THE MANUFACTURER IN ROLLS 1.0M WIDE OR A CUT TO SIZE SHEET MAY BE SUPPLIED IN THE JOINT KIT.
2. REFER JOINT DRAWINGS S02-02-02-23, 24 25 AND 26 FOR CABLE PREPARATION AND TERMIMESH DIMENSIONS.
3. THE METHOD OF JOINING, FOLDING & CLAMPING TERMIMESH IS CRITICAL TO ENSURE THAT THE TERMITE BARRIER CAN NOT BE BREACHED.
4. FOR NYLON JACKETED XLPE CABLES, THE TERMIMESH ENDS SHALL BE CLAMPED ONTO THE CABLES NYLON JACKET. FOR CHEMICAL PROTECTED CABLES, CLAMP TERMIMESH ONTO THE HDPE SHEATH.
5. USE GLOVES WHEN HANDLING TERMIMESH AS THE FINE WIRES CAN ABRASE SKIN.



STEP 5

CAREFULLY FORM A 'BOX PLEAT' AT EACH END TO FIT NEATLY AROUND THE NYLON JACKET OF THE CABLE.



STEP 6

APPLY STAINLESS STEEL HOSE CLAMPS OR ROLL SPRINGS AT EACH END. DO NOT OVERTIGHTEN HOSE CLAMPS - JUST FIRM IS SUFFICIENT.



4	SPELLING CORRECTIONS	C.W.M.	FEB'20	B.V.	B.V.
3	TITLEBLOCK & DRAWING NUMBER FORMATTED	K.T.	FEB'19	C.C.	C.C.
2	NOTE 4 AMENDED. CROSS SECTION ADDED	C.M.	NOV'12	A.T.	B.C.
1	NOTE 4 AMENDED FOR TERMITEX APPLICATION	K.I.	JUL'05	C.C.	C.C.
0	ISSUED FOR CONSTRUCTION	K.I.	JUN'05	C.C.	C.C.
NO	DESCRIPTION	DRN	DATE	CKD	APPD
AMENDMENTS					



DES	...	POWER STANDARD DRAWING		
DRN	J.A.L	<b>CABLE JOINTING AND TERMINATIONS                  TERMIMESH APPLICATION                  11 AND 22KV XLPE CABLE JOINTS</b>		
CKD	A.T.			
APPD	P.J.D.			
SCALE	N.T.S.			
ISSUED	DEC'95	A3	DRAWING NUMBER	S02-02-02-22
ALL DIM.	IN mm			
DRAFTING STANDARD TO A.S.1100		CAD PRODUCT - DO NOT AMEND MANUALLY		